

# THE BREWMASTER SAFETY RETROFIT KIT

1. Your retrofit kit includes an assembled retention collar and a 5/32 allen wrench.



2. Remove the parts from the bag and separate the halves of the retention collar using the supplied allen wrench (retain screws for reinstallation).



3. Place the retention collar halves around your brewmaster pulley shaft with the pin sides down into the hub. Be sure collar is fully seated against the hub.



4. Using the long end of the 5/32 allen wrench, insert the two previously removed screws into collar and lightly tighten, enough that the collar halves are lined up straight to each other and just touching.



5. Turn allen wrench and, using the short end, tighten the two screws as tight as possible.



With the retention collar securely in place, safe operation of The Brewmaster system may resume.

Questions or concerns? Email: [recall@fanimation.com](mailto:recall@fanimation.com) Phone: (888) 567-2055 Fax: (317) 536-3202



/fanimation



@fanimation



/FanimationFans



/FanimationFan



fanimation.com



888.567.2055

american  
lighting  
association