Ceiling Fan Light Kit Installation Instructions - Model F423** READ AND SAVE THESE INSTRUCTIONS

"Suitable for use in damp locations" — Weight: 2.87 lbs (1.30 kgs)

NOTE: Ceiling fan light kits are only meant to be used with ceiling fans. Do NOT install as a light fixture.

WARNING: To reduce the risk of fire or electric shock, do not use this fan/light kit with any solid-state speed control device.

CAUTION

Turning off wall switch is not sufficient. To reduce the risk of fire and electrical shock, be sure electricity is turned off at the main fuse box to the fan before installing the light kit.

1. Remove cover switch housing.



4. Locate white and blue wires labeled "FOR LIGHT".



7. Install 3 minican bulbs in each of the sockets.



2. Remove threaded plug from cover switch housing.



5. Connect white-to-white and blue-to-black wires with wire nuts.



8. Assemble glass bowl with bowl cap and finial nut provided, do not over-tighten.

A WARNING

To avoid possible fire or shock, make sure that the electrical wires are completely inside the fan housing and not pinched between the switch cup housing and the switch cover housing.



10983 Bennett Parkway Zionsville, IN 46077 (888) 567-2055 • FAX (866) 482-5215 Outside U.S. call (317) 733-4113 Visit Our Website www.fanimation.com

CAUTION

To reduce the risk of fire and electrical shock, this light kit should be used only with the fan model listed below:

Manufacturer: Fanimation, Inc. – Fan Model: # FP8009**



3. Place large rubber washer (provided) between fitter and cover switch housing before attaching cover switch housing to fitter with lockwasher and nut provided.



6. Assemble cover switch housing/fitter assembly with original screws.

A WARNING

To reduce the risk of fire, electric shock, and injury to person, F423** must be installed with G*** (Bowl glass) that are marked on F423** to indicate the suitability with this model. Other F423** cannot be substituted.

Copyright 2010 Fanimation